



Audi A7 / S7 / RS7 Sportback

from 2018



Note: The Rescue Sheet depicts a LHD vehicle (as allowed under the ISO 17840-1). All components (other than steering wheel and passenger airbag) are located in the same position in the Aust/NZ RHD model.

WARNING 48 V: Electric arc possible! Turn off ignition before separating the 48 V battery!



Legend

	Airbag		Reinforce-ment		Control module		Pedestrian protection system
	Gas-generator		Rollover-protection		Battery		
	Pretensioner		Gas-pressure damper		Fuel tank		


This document is a subject to the copyright of AUDI AG, Ingolstadt. Any duplication, distribution, storage, communication, broadcast and reproduction or transmission of the contents without written approval from AUDI AG is prohibited.

▶ Audi A7 / S7 / RS7 Sportback 48 V Mildhybrid

from 2018

12 V lead acid battery

- remove the battery cover
- separate the minus pole of the 12V battery



48 V Lithium-ion battery

⚠ The 48 V on-board Lithium-ion battery is automatically deactivated during accidents in which the airbag(s) deployed.



For all other cases, in order to deactivate the on-board power supply the 48 V Lithium-ion battery has to be separately disconnected in addition to the 12 V lead acid battery. Therefore:

⚠ WARNING! Hazard due to electric arc at 48 V

⚠ Turn off ignition before separating the 48V battery!

For minimization the risk of electric arc it is recommended to disconnect the batteries as follows:

1. remove the cargo floor from the trunk
2. remove the spare tire and vehicle tool kit
3. strip the lining of the spare wheel recess as shown below



4. pull out the communication connector plug
5. remove the right sided pole cap and separate the minus pole of the 48 V Lithium-ion battery.

