



HIACE

STANDARD ROOF



/ RHD

2019-2






	IG/POWER SW		Fuse Box		12V Battery
	Airbag (incl. Inflator)		Inflator		Fuel Tank
	Gas-filled Damper		Seat Belt Pretensioner (Gas Generator)		Structural Reinforcements
	Airbag Computer	—	—	—	—
—	—	—	—	—	—




Disable Vehicle






or



Access to 12V Battery






Towing Information




HIACE

HIGH ROOF / RHD

2019-2




TOYOTA
HIACE




	IG/POWER SW		Fuse Box		12V Battery
	Airbag (incl. Inflator)		Inflator		Fuel Tank
	Gas-filled Damper		Seat Belt Pretensioner (Gas Generator)		Structural Reinforcements
	Airbag Computer	—	—	—	—
—	—	—	—	—	—


Disable Vehicle



or



Access to 12V Battery



Towing Information

