




Note: The Rescue Sheet depicts a LHD vehicle (as allowed under the ISO 17840-1). All components (other than steering wheel and passenger airbag) are located in the same position in the Aust/NZ RHD model.



- ① On-board electrical system battery ② Additional battery (option)

Legend

- | | | | |
|--------------------------------|---------------|---------------------|-----------|
| Airbag | Gas generator | Seat belt tensioner | Fuel tank |
| Restraint systems control unit | 12 V Battery | | |