


# VOLVO XC90 (TYP L, 2015-)



Note: The Rescue Sheet depicts a LHD vehicle (as allowed under the ISO 17840–1). All components (other than steering wheel and passenger airbag) are located in the same position in the Aust/NZ RHD model.




## Legende

|  |               |  |                        |  |                 |  |                    |
|--|---------------|--|------------------------|--|-----------------|--|--------------------|
|  | Airbag        |  | Karosserie-verstärkung |  | Steuergerät     |  | mech. Sensor       |
|  | Gas-generator |  | Überroll-schutz        |  | Batterie        |  | Gastank            |
|  | Gurt-straffer |  | Gasdruck-dämpfer       |  | Kraftstoff-tank |  | Sicherheits-ventil |

# VOLVO XC90 T8 TWIN ENGINE (TYP L, 2015-)



Note: The Rescue Sheet depicts a LHD vehicle (as allowed under the ISO 17840-1). All components (other than steering wheel and passenger airbag) are located in the same position in the Aust/NZ RHD model.



## Legende

|  |                |  |                        |  |                 |  |                    |  |                              |
|--|----------------|--|------------------------|--|-----------------|--|--------------------|--|------------------------------|
|  | Airbag         |  | Karosserie-verstärkung |  | Steuergerät     |  | mech. Sensor       |  | Hochvolt-batterie            |
|  | Gas-generator  |  | Überroll-schutz        |  | Batterie        |  | Gastank            |  | Hochvolt-leitung/-komponente |
|  | Gurt-strauffer |  | Gasdruck-dämpfer       |  | Kraftstoff-tank |  | Sicherheits-ventil |  | HV-Trennstelle               |